


## Loveland Levers

If you would like to outfit your harp with Loveland Levers but don't know what size levers to order you can use the following chart. You will need to know the diameter of your strings and the vibrating length. You can measure the diameter of the strings with a vernier caliper or a micrometer. The vibrating length of each string is the distance between the soundboard and the guide pin.



Lever Size	Bracket Size	Diameter (inches)
#00	Small unfretted	.020-.025
#0	Small fretted	.025-.030
#2	Medium	.026-.031
#4	Medium	.032-.036
#6A	Medium	.037-.045
#5	Large	.036-.042
#7	Large	.043-.050
#9	Large	.050-.065
#12	Large	.065-.079
#14	Large	.80-.095

- The small unfretted bracket numbered 00 can be installed on strings with vibrating lengths less than 5.5"
- The small fretted brackets numbered 0 can be installed on strings with vibrating lengths between 5.5" - 8.5"
- The medium lever brackets numbering 2 - 6A can be installed on strings with vibrating lengths between 8.5" - 14.5"
- The large lever brackets numbering 5-14 can be installed on strings with vibrating lengths longer than 14.5"