



### Instructions For Use

1. Cut out the template along the black line.
2. Place the template under strings. The gray lines should sit just below the stings.

**Note:** Every harp is handmade so the strings may not line up perfectly, but they should be close enough.

3. Tune the harp to the notes on the tuning chart.

**The number next to each note name indicates the octave.**

Middle C on a piano is C4. The numbers change every octave on the note C.

C3 is the C one octave below middle C.

D4 is the D just above Middle C.

C5 is the C one octave above middle C