

The Cheyenne Harp

STRING CHART

String	Note	Gauge	Code	Color	Vibrating Length	Loveland Lever
1	C7	.025	CHEY-C7	red	3-7/8"	00
2	B6	.025	CHEY-B6	clear	4-1/2	00
3	A6	.025	CHEY-A6	clear	5-1/8	00
4	G6	.025	CHEY-G6	clear	5-3/4	00
5	F6	.028	CHEY-F6	blue	6-1/4	0
6	E6	.028	CHEY-E6	clear	7	0
7	D6	.028	CHEY-D6	clear	7-1/2	0
8	C6	.028	CHEY-C6	red	8	0
9	B5	.028	CHEY-B5	clear	8-3/4	0
10	A5	.032	CHEY-A5	clear	9-1/4	2
11	G5	.032	CHEY-G5	clear	10	2
12	F5	.036	CHEY-F5	blue	10-3/4	4
13	E5	.036	CHEY-E5	clear	11-1/2	4
14	D5	.040	CHEY-D5	clear	12-3/8	6A
15	C5	.040	CHEY-C5	red	13-1/4	6A
16	B4	.040	CHEY-B4	clear	14-1/4	5
17	A4	.040	CHEY-A4	clear	15-1/4	5
18	G4	.045	CHEY-G4	clear	16-5/8	7
19	F4	.045	CHEY-F4	blue	18	7
20	E4	.045	CHEY-E4	clear	19-1/4	7
21	D4	.050	CHEY-D4	clear	20-3/4	7
22	Mid C4	.050	CHEY-C4	red	22-1/4	7
23	B3	.050	CHEY-B3	clear	24	7
24	A3	.055	CHEY-A3	clear	25-7/8	9
25	G3	.045/.008 NN	CHEY-G3	clear	27-3/4	9
26	F3	.045/.010 NN	CHEY-F3	blue	29-1/2	9
27	E3	.050/.010 NN	CHEY-E3	clear	31-1/2	9
28	D3	.050/.013 NN	CHEY-D3	clear	33-1/2	12
29	C3	.050/.015 NN	CHEY-C3	red	35-1/2	12
30	B2	.055/.015 NN	CHEY-B2	clear	37-3/8	12
31	A2	.055/.018 NN	CHEY-A2	clear	39-1/2	12
32	G2	.026/8/.020 SFN	CHEY-G2	clear	41-1/2	9
33	F2	.024/5/.008 SFB	CHEY-F2	blue	43-1/2	7
34	E2	.024/6/.008 SFB	CHEY-E2	clear	45-1/2	7
35	D2	.024/6/.010 SFB	CHEY-D2	clear	47-1/2	9
36	C2	.026/6/.012 SFB	CHEY-C2	red	49-3/8	9

Includes 20 wooden dowels for upper string knots.

Learn how to replace or install harp strings

www.harokit.com/blog/how-to-string-a-harp/