

# The Voyager Harp

## STRING CHART

String	Note	Gauge	Code	Color	Vibrating Length	Loveland Lever
1	A6	.025	VOY-A6	clear	5'	00
2	G6	.028	VOY-G6	clear	5-1/2"	00
3	F6	.028	VOY-F6	blue	6-1/8	00
4	E6	.028	VOY-E6	clear	6-5/8	00
5	D6	.028	VOY-D6	clear	7-1/4	00
6	C6	.028	VOY-C6	red	8	0
7	B5	.028	VOY-B5	clear	8-5/8	0
8	A5	.032	VOY-A5	clear	9-1/2	2
9	G5	.032	VOY-G5	clear	10-1/4	2
10	F5	.036	VOY-F5	blue	11-1/4	4
11	E5	.036	VOY-E5	clear	12-1/4	4
12	D5	.036	VOY-D5	clear	13-1/4	4
13	C5	.040	VOY-C5	red	14-5/8	5
14	B4	.040	VOY-B4	clear	15-5/8	5
15	A4	.040	VOY-A4	clear	17	5
16	G4	.045	VOY-G4	clear	18-1/4	7
17	F4	.045	VOY-F4	blue	19-3/4	7
18	E4	.045	VOY-E4	clear	21	7
19	D4	.050	VOY-D4	clear	22-3/4	9
20	Mid C4	.050	VOY-C4	red	24-1/4	9
21	B3	.050	VOY-B3	clear	26	9
22	A3	.055	VOY-A3	clear	27-1/2	9
23	G3	.045/.010	VOY-G3	clear	29-1/4	12
24	F3	.050/.010	VOY-F3	blue	31	12
25	E3	.050/.010	VOY-E3	clear	32-3/4	12
26	D3	.050/.013	VOY-D3	clear	34-1/2	12
27	C3	.055/.013	VOY-C3	red	36	14
28	B2	.022/5/.015 SFB	VOY-B2	clear	38-1/4	9
29	A2	.024/8/.015 SFB	VOY-A2	clear	40	9
30	G2	.022/3/.008 SFB	VOY-G2	clear	41-1/2	9
31	F2	.022/5/.009 SFB	VOY-F2	blue	43	9
32	E2	.024/4/.010 SFB	VOY-E2	clear	44-5/8	9
33	D2	.024/8/.010 SFB	VOY-D2	clear	46-1/4	9
34	C2	.026/6/.012 SFB	VOY-C2	red	47-3/4	9

Includes 18 wooden dowels for upper string knots.

Learn how to replace or install harp strings

[www.harokit.com/blog/how-to-string-a-harp/](http://www.harokit.com/blog/how-to-string-a-harp/)